

# FLEXPOST-SM™ ANCHORING INSTRUCTIONS FOR ADHESIVE

## Tools Required:

- Marker
- Gloves
- Standard Caulk Gun
- Rag

## Parts Included:

- 1 Base Plate
- 1 MasterWeld 948

**NOTE: THIS ADHESIVE PRODUCT IS NOT INTENDED TO BE USED ON ASPHALT**



- 1**
- *Ensure that the application area is free of dirt, grease, oil, and moisture*
  - *Place the base in desired location and use a marker to outline the exterior and interior of the base*



- 2**
- *Using the MasterWeld 948, glue the area within the outline*
  - *Don't glue the inside center hole*



- 3**
- *Place the base on the adhesive within the drawn lines*



- 4**
- *Adhesive will come out the sides. Use a rag to wipe excess. Wait 24 hours for adhesive to be fully cured*

**FLEX**  
**POST**

2236 112th Ave, Suite 80  
Holland, MI 49424  
616-928-0829 • [www.FlexpostInc.com](http://www.FlexpostInc.com)