

FlexPost-SM™

SM-48 Channelizer Post

Installation Guide

1. Preparation

- Assemble the materials and tools needed

2. Installation

- Insert top section of post into the base
- Align pin hole with the base
- Insert locking pin to secure post to base
- Place base, mark 4 holes
- Drill 4 holes with 3/16" drill bit

3. Removal

- Remove locking pin
- Lift post from base

