

IMPORTANT: WEAR SAFETY GLASSES • CHECK UNDERGROUND FACILITIES

- Tools Required:**
- Mallet / Hammer
 - Wax Pencil / Marker
 - Tape Measure
 - 7/8" Masonry Drill Bit
 - 9/16" Ratchet
 - Measuring Cup
 - 3/8 Cup of Water
 - 3/16" Allen Key

- Parts Included:**
- 1 XL Unit
 - 4 HD Anchors, Washers, 9/16 Bolts
 - 2 Bags of Grout



**DO NOT PLACE
WITHIN 10"
OF ANY CURB**



MARK 4 HOLES



**MARK YOUR
DRILL BIT AT 6"**



**DRILL 4 HOLES
7/8" DIAMETER
6" DEEP**



**CLEAR AWAY ANY
DUST OR DEBRIS**



**MEASURE 3/8 CUP WATER
GATHER ALL MATERIALS
PRIOR TO MIXING GROUT!**



**SLOWLY MIX APX.
3/8 CUP WATER WITH
GROUT MIXTURE
(DON'T DUMP ALL THE WATER,
ADD JUST A LITTLE AT A TIME)**



**KNEAD TO SYRUP
CONSISTENCY
(ONLY MIX ONE BAG
AT A TIME!)**



**POUR MIXTURE INTO
THE 4 HOLES
(ONE BAG PER TWO HOLES)**



**USING A RUBBER
MALLETT, TAP BOLTS
INTO THE HOLES**



**WITH A DAMP CLOTH,
WIPE AWAY ANY EXCESS**



**USING A 9/16"
RATCHET,
TIGHTEN BOLTS**

