


# FLEXPOST-SM™ ANCHORING INSTRUCTIONS FOR CONCRETE

## Tools Required:


- Marker / Wax Pencil
- High Speed Power Drill
- 3/8" Masonry Drill Bit
- Philips Screwdriver
- Socket Wrench with 9/16" drive

## Parts Included:


- 1 Base Plate
- 4 Concrete Wedge Bolts
- (1) 5/8" Philips Set Screw




- 1**
- Place base plate in desired anchoring location
  - Mark the four base holes before drilling




- 2**
- Using a 3/8" masonry bit, drill 3" in depth




- 3**
- Place the base plate over the four holes and use a socket wrench with a 9/16" drive to thread all four wedge bolts



- 4**
- Insert the post into the base plate



- 5**
- Turn counter-clockwise 45° to set it in place



- 6**
- With a philips screwdriver, install the 5/8" set screw to lock in securely

**FLEX**  
**POST**®

2236 112th Ave, Suite 80  
Holland, MI 49424  
616-928-0829 • [www.FlexpostInc.com](http://www.FlexpostInc.com)